FlexNet-Driver-Documentation LPBCK.EXE (C)1996 Bernhard Feller DL8MAS

Date: 6/22/96

Ident: LPBCK

PC/Flexnet-Driver for selfconnecting in a Flexmini-enviroment (LooPBaCK).
for testing/connect of FLEXNET-TSR-application's.

Example of installation of LPBCK on port 5 & 6:

```
flexnet 20
rem HF-port 1200 Bd on channel 0
ser12 1
rem 4 port 1..4 reserved
dummy 4
rem install Loop-Back on port 5 & 6
lpbck 2
rem .. initialize flexnet-drivers as neccessary  (FSET ...)
rem ... start application/terminal-program etc.
```

than you can perform selfconnects via channel 5, 6
(example: BayomTerminal BCT,Terminal-Application):

```
:XCONNECT DL8MAS-3 DL8MAS 5
```

or if there is a TSR-Application installed, you can connect it
(if TSR-appl.-call = DL8MAS-10):

```
:CONNECT DL8MAS-10 6
```

Author: Bernhard Feller
DL8MAS @ DB0AAB.#BAY.DEU.EU